## Wall Box — APP Function Manual



V1.2.4

Attention: the documentation is only applicable for the wallbox version which has the OCPP and Normal APP function and switch freely.

#### Contents

Wall Box — APP Function Manual	1 -
1 Download and install	3 -
2 Register	4 -
3 Login APP	5 -
4 Forget password	6 -
5 Add charging station	7 -
5.1 Add charging station via Bluetooth(recommended)	7 -
6 List of charging station	12 -
7 Start and stop charging	13 -
8 Reserve charge	14 -
9 IC card activated charging	17 -
10 Device details	18 -
11 Parameter setting	19 -
12 Function setting	21 -
13 Load balancing	28 -
14 Charging station share	32 -
15 Personal information	34 -
16 Message center	35 -
17 Help & feedback	36 -
18 Privacy Agreement	39 -
19 About APP	40 -
20 Revision History	41 -

### 1 Download and install

Android phone users can search and install "DS charge" through Google play. Iphone users can search and install "DS charge" through the APP store.






Note: All APP functions require charging station to be connected to the router and connected to the Internet.


# 2 Register

When the user first visits, the user registration is performed by the following steps.




Users will then receive an email to activate their account.

# 3 Login APP



Please use your account and password to log in.

# 4 Forget password



Press "Forget password", and then you will receive an email to change your password.

## 5 Add charging station


#### 5.1 Add charging station via Bluetooth(recommended)




Pull down and refresh to appear Bluetooth devices



Click into the device and select the top right corner



Select 'Configure Network '




- 1 Select the SSID of the router.
- 2 Enter your WiFi connection password.
- 3 Select the WebSocket connection.
- 4 Select ws or wss connection mode, And enter OCPP URL,

The default: cpam3.x-cheng.com:443/ocpp

If connected to other OCPP platform, Please refer to the format


below: {IP Address or domain name}:{Port}/{path}

The URL given by the platform may not have a port number, please fill in the port number in the example. The default encrypted connection is 443, Unencrypted connection is 80.




It will take about 2 minutes to configure the network. After success, name the charging station.

# 6 List of charging station




Successful charging station will appear in this area.

## 7 Start and stop charging




You can use the APP to start and stop charging remotely.


## 8 Reserve charge



Press "Reserve Charge" into reserve charging list page, And press "Add Period" to add new reserve charge schedule.



Setting reserve charge once or cycle.



Then select the start time and end time, And "Confirm" it.

Note 1: Turn on or off the scheduled charging schedule.


# 9 IC card activated charging



- 1 Plugging the connector into the vehicle socket.
- 2 Swing IC card and start charging.


Note: See Chapter 12 for IC card setup. And close "plug & play mode".

#### 10 Device details



- 1 State of charging station. 2 Energy of charging.
- 3 Time spent on the current charging plan.
- 4 Remaining available power(kWh) of user.
- 5 Display start and end time of reserve charge.
- 6 Max charging current. 7 Current of charging.
- 8 The voltage of charging station.
- 9 Current charging power. 10 Internal temperature of charging station.

### 11 Parameter setting




- 1:Working current: Sets the maximum allowable charge current.
- 2:LED Brightness: Adjust the brightness of LED indicator light of charger.
- 3: Plug & play mode: Users can charge directly after plug the charging connector in vehicle.
- 4: Some older electric vehicles do not comply with the latest IEC regulations. ERR01 will appear on the charger screen.

This error prompt can be turned off by this switch without causing charging safety issues.


5: Turning on the switch will allow shared users to use the reservation charging feature.

# 12 Function setting




### 1 Charge record

User can see the charging history.




#### 2 Device name

User can rename the charging station.



### 3 Firmware update


User can check the charging station firmware update.




#### 4 IC management




Swipe the IC card on the RFID symbol of the charging station.






5 User can delete the charging station.




# 13 Load balancing




Step 1: Select the Load balancing in APP menu.

Step 2: Press the ADD GROUP.



Step 3: Select the required load balanced charging stations.

Step 4: Set Group name and Group Max current.




When multiple charging stations in the group are charged at the same time, The charging stations will distribute the current equally, if total current of the charging stations reaches the group limit max current.

### 13.1 Load management off line function

When one or more Wallboxes in the load balancing group are offline, Off-line charging stations will be charged at a safe current(Offline Charging Current), The remaining online charging stations continue to be controlled by the backend load balancing function. All of this is automatic and the user does not need to make any setup for off-line load balancing. After the load balancing group is created, the background will assign an Offline Charging Current value to the Wallbox, which will be used for charging when the Wallbox is offline. The offline Wallbox will also be regarded as the charging state using the offline current value, and the remaining online Wallbox will continue to be controlled by the load balancing function of the background.


Note: Charging station must be OCPP version, and The version must be V2.5 302 or later.

# 14 Charging station share



Step 1: Press charging station share in APP menu.


Step 2: Press symbol +.



Step 3: Fill in the sharing user's e-mail, Select charger station to share. And it can limit the amount of energy users can charge.

Step 4: Completed sharing.


### 15 Personal information



Step 1: Press the icon from the menu to enter personal setting.


Step 2: User can change the Avatar and password in this page.

# 16 Message center




The message center contains system messages and feedback.

# 17 Help & feedback




The FAQ and user's manual can be found here, and user can feedback questions.

#### 1. Feedback




Submit


### 2. Help



### 18 Privacy Agreement



### 19 About APP



User can check software updating information in this page.

# 20 Revision History

V1.0 First release.